

**Lawn Mowers Greater than 5 Ah for \$40 Rebate**

**January 1 - December 31, 2021**

**Updated: 11/01/2021**

**\*Qualified list may be subject to change**

Brand Name	Model Number	Ah	Additional Model Info	Volt
Craftsman	CMCMW270Z1	7.5	V60* Cordless 21-In. 3-In-1 Self-Propelled Lawn Mower Kit (7.5Ah)	60
DeWalt	DCMW220X2	9	20 in. 20-Volt MAX Lithium-Ion Cordless Walk Behind Push Lawn Mower w/ (2) 9.0 Ah Batteries and Charger	20
DeWalt	DCMW220X2C	9	20 in. 20-Volt MAX Lithium-Ion Cordless Walk Behind Push Lawn Mower with Two 9.0 Ah Batteries and 2 Chargers	20
DeWalt	DCMW290H1	6	20 in. 40-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower w/ (1) 6.0 Ah Battery and Charger	40
DeWalt	DCMWP233U2	10	21.5" Lithium Ion Push Mower	40
DeWalt	DCMWSP244U2	10	21.5" Lithium Ion Self-Propelled Mower	40
EGO	LM2022SP	7.5	20 In. Brushless Steel Deck Walk Behind-Self Propelled, Cordless Mower Kit 7.5 Ah Battery/Charger Included	56
EGO	LM2102SP	7.5	21 In. 56-Volt Lithium-Ion Cordless Walk Behind Self Propelled Mower Kit	56
EGO	LM2135SP	7.5	21 In. Select Cut 56-Volt Lith-Ion Cordless Electric Walk Behind Self Propelled Lawn Mower, Battery And Charger Included	56
EGO	LM2156SP	10	EGO POWER+ Select Cut XP 56-Volt Brushless 21-in Self-propelled Cordless Electric Lawn Mower 10 Ah (Battery and Charger Included)	56
Henx	H40GC16	7.5	16 in. 40-Volt Cordless Battery Hand Walk Behind Push Mower with Battery/Charge Included	40
Henx	H40GC20	7.5	20 in. 40-Volt Cordless Battery Hand Walk Behind Push Mower with Battery/Charge Included	40
Kobalt	KMP6080-06	6	Kobalt 80-Volt Max Brushless 21-in Self-Propelled Cordless Electric Lawn Mower 6 Ah (Battery Included and Charger Included)	80
Oregon	591078	6	LM400 40-volt Brushless Lithium Ion Push 20-in Cordless Electric Lawn Mower	40
Oregon	591081	6	16 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower with 6.0 Ah Battery and Rapid Charger	40
Oregon	591083	6	16 In. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - Battery And Charger Not Included	40
Robomow	RS630	6	RS630 22 in. Twin Blade Battery Powered Electric Robotic Lawn Mower (Up to 3/4 Acre)	26
RYOBI	RY40110-Y	6	20 In. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 6.0 Ah Battery/Charger Included	40
RYOBI	RY401110	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 6.0 Ah Battery/Charger Included	40
RYOBI	RY401110-2B	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower (2) 6.0 Ah Batteries & Charger Included	40
RYOBI	RY401110-2X	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower & Blower with 6.0 Ah Battery & Charger	40

**Lawn Mowers Greater than 5 Ah for \$40 Rebate**

**January 1 - December 31, 2021**

**Updated: 11/01/2021**

**\*Qualified list may be subject to change**

Brand Name	Model Number	Ah	Additional Model Info	Volt
RYOBI	RY401110-4X	6	20 in. 40-Volt Lithium-Ion Brushless Cordless Battery Walk Behind Push Lawn Mower & Trimmer w/ 6.0 Ah Battery & Charger	40
RYOBI	RY401110-Y	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 6.0 Ah Battery/Charger Included	40
RYOBI	RY401120-2B	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Self-Propelled Walk Behind Mower with 2 6.0 Ah Batteries, Charger Included	40
RYOBI	RY401120-2X	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Self-Propelled Walk Behind Lawn Mower & Blower w/6.0 Ah Battery & Charger	40
RYOBI	RY401120-4X	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Walk Behind Self-Propelled Mower & Trimmer w/6.0 Ah Battery & Charger	40
RYOBI	RY401120-Y	6	20 In. 40-Volt 6.0 Ah Lithium-Ion Battery Brushless Cordless Walk Behind Self-Propelled Lawn Mower With Charger Included	40
RYOBI	RY401130, RY401130-CMB1	7.5	21 in. 40-Volt Lithium-Ion Brushless Cordless Walk Behind Self-Propelled Mower with 7.5 Ah Battery/Charger Included	40
RYOBI	RY401140US	6	40V HP Brushless 21 in. Cordless Battery Walk Behind Self-Propelled Lawn Mower with (2) 6.0 Ah Batteries and Charger	40
RYOBI	RY401140US-Y	6	21 in. 40-Volt HP Lithium-Ion Brushless Cordless Walk Behind Self-Propelled Lawn Mower - Two 6.0 Ah Batteries & Charger	40
RYOBI	RY401150US	6	RYOBI40V HP Brushless 21 in. Cordless Battery Walk Behind Dual-Blade Self-Propelled Mower with (2) 6.0 Ah Batteries & Charger	40
RYOBI	RY401150US-Y	6	21 in. 40-Volt HP Lithium-Ion Battery Brushless Walk Behind Dual-Blade Smart-Trek Mower - Two 6.0 Ah Batteries & Charger	40
RYOBI	RY40LM10-Y	6	21 In. 40-Volt Brushless Lithium-Ion Cordless Smart Trek Self-Propelled Walk Behind Mower With 6.0Ah Battery And Charger	40
RYOBI	RY40LM30	6	20 In. 40-Volt Brushless Lithium-Ion Cordless Smart Trek Self-Propelled Walk Behind Mower W/6.0 Ah Battery And Charger	40
RYOBI	RY40LM30-2B	6	20 in. 40-Volt Brushless Lithium-Ion Cordless Smart TREK Self-Propelled Walk Behind Mower Two 6.0 Ah Batteries & Charger	40
Toro	20361	6	Recycler 22 In. 60-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - 6.0 Ah Battery/Charger Included	60
Toro	20363	6	Recycler 22 In. 60-Volt Lithium-Ion Cordless Battery Walk Behind Personal Pace Mower - 6.0 Ah Battery/Charger Included	60
Toro	20366	7.5	22 In. Recycler 60-Volt Lithium-Ion Cordless Battery Walk Behind Personal Pace Mower - 7.5 Ah Battery/Charger Included	60
Toro	21356	6	Recycler 21 in. SmartStow 60-Volt Lithium-Ion Brushless Cordless Battery Walk Behind Mower RWD 6.0 Ah w/ Battery&Charger	60
Toro	21466	6	Recycler 22 in. SmartStow 60-Volt Max Lithium-Ion Cordless Battery Walk Behind Mower, 6.0 Ah Battery/Charger Included	60