## Lawn Mowers 4-5 Ah for \$30 Rebate January 1 - December 31, 2021 Updated: 11/01/2021 \*Qualified list may be subject to change

Brand Name	Model Number	Ah	Additional Model Info	Volt
Craftsman	CMCMW260P1	5	V60* Cordless 21-In. 3-In-1 Lawn Mower Kit (5.0Ah)	60
Craftsman	CMCMW270P2	5	V60* Cordless 21-In. 3-In-1 Self-Propelled Lawn Mower Kit (2X 5.0Ah)	60
DeWalt	DCMW220P2	5	20 In. 20-Volt Max Lithium-Ion Cordless Walk Behind Push Lawn Mower W/ (2) 5.0 Ah Batteries And Charger	20
Dewalt	DCMW220P2DCB2 052	5	20 in. 20-Volt MAX Lithium Ion Cordless Battery Walk Behind Push Lawn Mower w/ (4) 5.0 Ah Batteries and Charger	20
Echo	CLM-58V4AH	4	21 in. 58-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - 4.0 Ah Battery/Charger Included	58
EGO	LM2101	5	21 In. 56V Lithium-Ion Cordless Electric Walk Behind Push Mower, 5.0 Ah Battery And Charger Included	56
EGO	LM2133	5	21 In. 56-Volt Select Cut Lithium-Ion Cordless Electric Walk Behind Push Mower With 5.0 Ah Battery And Charger	56
EGO	LM2142SP	5	21 In. 56V Lithium-Ion Cordless Electric Dual-Port Walk Behind Self Propelled Mower, Two 5.0 Ah Batteries Included	56
EGO	LM2142SP	5	21 In. 56-Volt Lith-Ion Electric Cordless Poly Deck Dual-Port Self Propelled Walk Behind Mower 2X 5.0Ah Batteries	56
Green Machine	GM192907	4	62-Volt Cordless 3-in-1 High Wheel Push Walk Behind Mower, Cutting Width 22 in. with 4 Ah Battery and Charger	62
Green Machine	GM193007	4	22 in. Cutting Width 62-Volt Cordless RWD Self Propelled 3-in-1 High Wheel Walk Behind Mower, 4Ah Battery And Charger	62
Greenworks	1302602	4	40V 20-Inch 20-Inch Dual Port Battery Lawn Mower With Bonus 2.5Ah Battery	40
Greenworks	1313702	4	17 in. 48-Volt Battery Cordless Lawn Mower with (2) 4.0 Ah Batteries, Charger and 24-Volt Drill Included	48
Greenworks	1313802	4	20 in. 48-Volt Battery Cordless Lawn Mower with (2) 4.0 Ah Batteries, Charger and 24-Volt Drill Included	48
Greenworks	1313902	5	20 in. 48-Volt Battery Cordless Self-Propelled Walk Behind Lawn Mower with (2) 5.0 Ah Battery Charger and 24-Volt Drill	48
Greenworks	2501202	4	80V 21-Inch Cordless Brushless Lawn Mower (1- 4Ah Battery)	80
Greenworks	2516402	5	21 in. 40-Volt Battery Cordless Self-Propelled Walk-Behind Lawn Mower with 5.0 Ah Battery and Quick Charger	40
Greenworks	2520002	4	60V 21 In. Mower With 4.0Ah Battery And Charger	60
Greenworks	2520102	5	60V Greenworks Pro 21 In. Cordless Self-Propelled Mower With 5.0Ah High Capacity Battery And Charger	60
Greenworks	2532502	5	21 in. 48-Volt Battery Cordless Self-Propelled Lawn Mower with (2) 24-Volt 5.0 Ah Battery and Dual Port Charger	48
Greenworks	2532802	4	20 in. 48-Volt Battery Cordless Walk Behind Lawn Mower with Two 4.0 Ah Batteries and Dual Port Charger	48
Greenworks	2532902	4	21 in. 48-Volt Battery Cordless Self-Propelled Lawn Mower with (4) 24-Volt 4.0 Ah Batteries and 2 Dual Port Chargers	48
Greenworks	2516102AZ	5	20 in. 40-Volt Cordless Twin Blade Lawn Mower with 5.0 Ah Battery and Charger	40
Greenworks	2524702AZ	4	13 in. 24-Volt Battery Walk Behind Push Mower, 4Ah USB Battery and Charger Included MO24B410	24
Greenworks	2526302AZ	4	17 in. 48-Volt (2 x 24-Volt) Battery Walk Behind Push Mower, 2 x 24-Volt 4Ah Batteries and Dual Port Charger Included	48
Greenworks	GLM801602	4	80V 21-Inch Cordless Brushless Lawn Mower (2- 2Ah Batteries)	80
Greenworks	LMB408	4	Greenworks 80V Lithium-Ion 21" Self Propelled Mower With Two Batteries and Charger	80
Greenworks	LMC415	4	PRO 17 in. 60-Volt Battery Cordless Smart Pace Walk-Behind Lawn Mower with 4.0 Ah Battery and Charger	60
Greenworks	MO40L410	4	20 in. 40-Volt Battery Cordless 3-in-1 Lawn Mower with 4.0 Ah Battery and Charger	40
Greenworks	MO40L4413	4	21 in. 40-Volt Battery Walk Behind Self-Propelled Lawn Mower with (2) 4.0 Ah USB Battery and Charger	40
Greenworks	MO60L518	5	Pro 19 in. 60-Volt Lithium-ion Cordless Walk Behind 2 in 1 Mower with 5.0 Ah Battery and 3.0 Ah Charger Included	60
Kobalt	KM 2041B	5	40-Volt Max Brushless Lithium Ion Push 20-In Cordless Electric Lawn Mower	40
Kobolt	KM2041B-06	5	Kobalt 40-Volt Max Brushless Lithium Ion Push 20-In Cordless Electric Lawn Mower	40
Kobolt	KM5080-06	5	Kobalt 80-Volt Max Brushless Lithium Ion Push 21-In Cordless Electric Lawn Mower	80
Kobolt	KMP5040-06	5	Kobalt 40-Volt Max Brushless Lithium Ion Self-Propelled 20-In Cordless Electric Lawn Mower	40

## Lawn Mowers 4-5 Ah for \$30 Rebate January 1 - December 31, 2021 Updated: 11/01/2021 \*Qualified list may be subject to change

Brand Name	Model Number	Ah	Additional Model Info	Volt
Makita	XML02PT,XML02PT- XMU04Z, XML02PT- DML815	5	18V X2 (36V) Lxt Lithium-Ion Cordless (5.0Ah) 17" Lawn Mower Kit	36
Makita	XML03CM1	4	18 in. 18-Volt X2 (36-Volt) LXT Lithium-Ion Cordless Walk Behind Push Lawn Mower Kit with 4 Batteries (4.0 Ah)	36
Makita	XML03PT1	5	18V X2 (36V) Lxt Lithium-Ion Brushless Cordless (5.0Ah) 18" Lawn Mower Kit With 4 Batteries	36
Makita	XML05PT	5	18-Volt X2 (36V) LXT Lithium-Ion Cordless 17 in. Walk Behind Residential Lawn Mower Kit (5.0Ah)	36
Makita	XML06PT1	5	18-Volt X2 (36-Volt) LXT Lithium-Ion Cordless 18 in. Walk Behind Self Propelled Lawn Mower Kit with 4 Batteries (5.0 Ah)	36
Makita	XML07PT1	5	18-Volt X2 (36-Volt) LXT Lithium-Ion Cordless 21 in. Walk Behind Push Lawn Mower Kit with 4 Batteries (5.0 Ah)	36
Makita	XML08PT1	5	18-Volt X2 (36-Volt) LXT Lithium-Ion Cordless 21 in. Walk Behind Self Propelled Lawn Mower Kit with 4 Batteries (5.0 Ah)	36
Makita	XML09PT1	5	21 in. 18-Volt X2 (36-Volt) LXT Lithium-Ion Brushless Cordless Walk Behind Self-Propelled Lawn Mower Kit (5.0Ah)	36
MOWOX	MNA192207	4	19 in. 62-Volt, 2-n-1 RWD Self Propelled Cordless High Wheel Walk Behind Mower with 4 Ah Lith-ion Battery and Charger	62
MOWOX	MNA192211	4	17 in. 40-Volt Battery Power RWD 3-in-1 Self Propelled Walk Behind Mower with High Wheel 4 Amp Battery Charger	40
MOWOX	MNA192601	5	20 in. 82-Volt Self-Propelled Cordless Walk Behind Mower with 5.0 Ah Battery and Charger	82
MOWOX	MNA192602	5	20 in. 82-Volt Cordless Self Propelled Variable Speed RWD Walk Behind Mower with 82-Volt 5.0 Ah Battery and Charger	82
Oregon	591079	4	LM400 40-volt Brushless Lithium Ion Push 20-in Cordless Electric Lawn Mower	40
Oregon	591082	4	16 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower with 4.0 Ah Battery and Charger	40
PowerSmart	PS76417	4	17 in. 40-Volt 3-in-1 Cordless Battery Walk Behind Push Lawn Mower with 4.0 Ah Battery and Charger	40
Powerworks	MO60L02PW	5	60V 21-Inch Sp Mower, Battery Not Included	60
Realm	RM-LM01-B2Z-340	4	14 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 4.0 Ah Battery/Charger Included	40
Redback	107477	4	18 in. 40-Volt Electric Lithium-Ion Walk Behind Push Lawn Mower Kit	40
Redback	107478	4	19 in. 40-Volt Electric Lithium-Ion Walk Behind Push Lawn Mower Kit	40
Remington	RM4060	5	21 in. 40-Volt Lithium-Ion 3-in-1 Cordless Walk Behind Push Mower - 5.0 Ah Battery/Charger Included	40
RYOBI	P1104, P1180- CMB1	4	13 in. ONE+ 18-Volt Lithium-Ion Walk Behind Push Lawn Mower/Blower/Chainsaw/Hedge/String Trimmer Kit (5-Tool)	18
RYOBI	P1104, P1180S-2X	4	13 in. ONE+ 18-Volt Lithium-Ion Battery Walk Behind Push Lawn Mower & String Trimmer - 4.0 Ah Battery/Charger Included	18
RYOBI	P1104, P1180S-4X	4	13 in. ONE+ 18-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower and Leaf Blower with 4.0 Ah Battery/Charger	18
RYOBI	P1109, P1190VNM- 4X	4	ONE+ HP 18-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower + Trimmer + Blower - (3) Batteries & Charger	18
RYOBI	P1111	4	16 In. One+ 18-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower Two 4.0Ah Batteries/Charger	18
RYOBI	P1121	4	16 in. One+ 18-Volt Lithium-Ion Hybrid Walk Behind Push Lawn Mower - Two 4.0 Ah Batteries/Charger Included	18
RYOBI	P1140-S	4	13 In. One+ 18-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - 4.0 Ah Battery/Charger	18
RYOBI	P1140S-2X	4	13 in. ONE+ 18-Volt Lithium-Ion Battery Walk Behind Push Lawn Mower & String Trimmer - 4.0 Ah Battery/Charger Included	18
Ryobi	P1180VNM	4	ONE+ 18V 13 in. Cordless Battery Walk Behind Push Lawn Mower with 4.0 Ah Battery and Charger	18
Ryobi	P1190VNM	4	ONE+ HP 18V Brushless 16 in. Cordless Battery Walk Behind Push Lawn Mower with (2) 4.0 Ah Batteries and (1) Charge	36
RYOBI	RY401100, RY401100-4X	4	18 in. 40-Volt 2-in-1 Lithium-Ion Cordless Battery Walk Behind Push Mower and Trimmer - 4.0 Ah Battery/Charger Included	40
RYOBI	RY401100-2B	4	18 in. 40-Volt 2-in-1 Lithium-Ion Cordless Battery Walk Behind Push Mower with Two 4.0 Ah Batteries and Charger Included	40
RYOBI	RY401100-Y	4	18 in. 40-Volt 2-in-1 Lithium-Ion Cordless Battery Walk Behind Push Mower 4.0 Ah Battery/Charger Included	40

## Lawn Mowers 4-5 Ah for \$30 Rebate January 1 - December 31, 2021 Updated: 11/01/2021 \*Qualified list may be subject to change

Brand Name	Model Number	Ah	Additional Model Info	Volt
RYOBI	RY40140	4	16 In. 40-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - 4.0 Ah Battery/Charger Included	40
RYOBI	RY40180	5	20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 5.0 Ah Battery and Charger Included	40
RYOBI	RY40180-Y	5	20 In. 40-Volt Brushless Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower 5.0 Ah Battery And Charger Included	40
RYOBI	RY40190	5	RYOBI 20 in. 40-Volt Brushless Lithium-Ion Cordless Battery Self Propelled Lawn Mower with 5.0 Ah Battery and Charger Included	40
RYOBI	RY40190-Y	5	20 In. 40-Volt Brushless Lithium-Ion Cordless Battery Self Propelled Lawn Mower With 5.0 Ah Battery And Charger Included	40
Scotts	60040S	5	19 in. 40-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower with 5 Ah Battery and Charger Included	40
Scotts	60062S	5	21 in. 62-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower with 5 Ah Battery and Charger Included	62
Scotts	60362S	4	21 in. 62-Volt Lithium-Ion Cordless Self-Propelled Walk Behind Mower with 4 Ah and 2.5 Ah Battery and Charger Included	62
Scotts	61940S	5	19 in. 40-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower with 5 Ah Battery and Charger Included	40
Scotts	62014S	4	62014S 14 in. 20-Volt Cordless Walk Behind Push Lawn Mower, 4.0Ah Battery and Faster Charger Included	20
Scotts	62162S	5	21 in. 62-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower with 5 Ah Battery and Charger Included	62
Skil	PM4910-10	5	PWR CORE 20 in. 40V Lith-Ion Brushless Cordless Electric Walk Behind Push Mower, 5.0Ah Battery and Charger Included	40
Skil	SM4910-10	5	PWR CORE 20 in. 40V Lith-Ion Brushless Electric Walk Behind Self Propelled Mower, 5.0Ah Battery and Charger Included	40
Snapper	1687966	5	HD 20 in. 48-Volt Lithium-Ion Cordless Battery Walk Behind Push Mower with 5.0 Ah Battery/Charger Included	48
Snapper	1688022	5	HD 20 in. 48-Volt Lithium-Ion Cordless Battery Walk Behind Self Propelled Push Mower with 5.0 Battery/Charger Included	48
Sun Joe	24V-CRLM15	4	24-Volt iON Plus Cordless Push Reel Mower Kit with 4.0 Ah Battery and Charger	24
Sun Joe	24V-MJ14C	4	14 in. 24-Volt Cordless Push Walk-Behind Mower Kit with 4.0 Ah Battery Plus Charger	24
Sun Joe	24V-X2-17LM	4	17 in. 48-Volt iON+ Cordless Electric Walk Behind Push Lawn Mower Kit with 2 x 4.0 Ah Batteries Plus Charger	48
Sun Joe	ION16LM	4	40-Volt 16-Inch Brushless Cordless Lawn Mower, Kit (W/4.0-Ah Battery + Quick Charger)	40
Sun Joe	ION16LM-HYB	4	15 in. 40-Volt Hybrid Battery Walk Behind Push Mower Kit with 4.0 Ah Battery + Charger	40
Sun Joe	MJ24C-14-XR	5	14 in. 24-Volt Cordless Walk-Behind Push Mower Kit with 5.0 Ah Battery + Charger	24
Sun Joe	MJ401C-XR	5	14 in. 28-Volt Brushless Cordless Walk-Behind Push Mower Kit with 5.0 Ah Battery + Charger	28
Sun Joe	MJ401C-XR-RED	5	14 in. 28-Volt Cordless Walk-Behind Push Mower Kit with 5.0 Ah Battery + Charger, Red	28
Sun Joe	MJ401C-XR-SJB	5	14 in. 28-Volt Cordless Walk-Behind Push Mower Kit with 5.0 Ah Battery and Charger, Blue	28
Toro	20367	4	Recycler 21 In. 60-Volt Lithium-Ion Cordless Battery Walk Behind Push Lawn Mower - 4.0 Ah Battery/Charger Included	60
WEN	40441	4	21 in. 40-Volt Max Lithium-Ion Cordless 3-in-1 Walk Behind Push Lawn Mower - 16 Gal. Bag, Two Batteries/Charger Included	40
WEN	40439	4	19 in. 40-Volt Max Lithium-Ion Cordless Battery 3-in-1 Walk Behind Push Lawn Mower - Two Batteries/Charger Included	40
WORX	WG743	4	POWER SHARE 40-Volt 17 in. Cordless Battery Walk Behind Mower with Mulching & Intellicut, (Battery & Charger Included)	40
WORX	WG744	4	POWER SHARE 40-Volt Li-ion 17 in. Cordless Battery Walk Behind Push Mower with Mulching (2 x 20-Volt Batteries)	40
WORX	WG751	5	POWER SHARE 40-Volt Li-ION Battery 20" 5.0Ah Push Mower w/ Mulching and Side Discharge Capabilities Walk Behind	40
WORX	WG779	4	POWER SHARE 40-Volt 14 in. Cordless Battery Walk Behind Mower with Mulching & Intellicut, (Battery & Charger Included)	40
WORX	WR140	4	20-Volt 7 In. 4.0 Ah Lithium-Ion Robotic Landroid M Mower, Brushless Wheel Motors, Wifi Plus Phone App	20
WORX	WR143	4	20-Volt 7 In. 4.0 Ah Robotic Landroid M Mower, Brushless Wheel Motors, Wifi Plus Phone App With Gps Module Included	20
WORX	WR150	4	20-Volt 9 In. 4.0 Ah Lithium-Ion Robotic Landroid L Mower, Brushless Wheel Motors, Wifi Plus Phone App	20
WORX	WR153	4	20-Volt 9 In. 4.0 Ah Robotic Landroid L Mower, Brushless Wheel Motors, Wifi Plus Phone App With Gps Module Included	20

## Lawn Mowers 4-5 Ah for \$30 Rebate January 1 - December 31, 2021 Updated: 11/01/2021

\*Qualified list may be subject to change

<b>Brand Name</b>	Model Number	Ah	Additional Model Info	Volt
Yard Force	YF60vRXSPM1	4	20 in. 60-Volt Cordless Brushless Lithium-ion 4.0Ah RWD Self-Propelled Lawn Mower, includes Battery and Charger	60